



Installation Instructions

Guardian Drain-Lock Hybrid

Tools Needed

You will need the following tools to properly secure the Guardian Drain-Lock:

- 3/8" Ratchet
- 3/8" Ratchet Extension
- Tamperproof Torx Key (#40 for 2" and #45 for 3" & 4" drain-locks)
- Rag

How to Install

- Clean the floor sink of debris and grim build up within the throat of drain. (Photo #1)
- Determine the appropriate size Guardian Drain-Lock to be installed: 2", 3" or 4". If any of these sizes do not fit in your floor sink contact Drain-Net at 908-236-0277. Once size is validated, place the Guardian Drain-Lock in the hole of the floor sink. Note: If you are using the Guardian Hybrid line the sticky tape can be removed to allow for a better fit.
- Assemble the ratchet, ratchet extension and tamperproof key. Determine which tamperproof key will be needed to secure the desired Guardian Drain-Lock. #40 key for 2" and #45 for 3" and 4".
- While holding down the drain-lock with one hand, insert the driver and key into the tamperproof bolt and tighten (clockwise) until firmly secured. Do not over tighten use judgment. (Photo #2)
- All locations are built differently and may need additional tools to reach the floor sink. Floor sinks may also differ in shape not allowing for the Guardian Drain-Lock to fit properly. If this is the case for you, contact Drain-Net at 908-236-0277.



Photo #1



Photo #2

Monitoring the Drain-lock

- Once the Guardian Drain-Lock is properly secured and locked there should be no need to remove it other than for sanitation purposes. As needed use soapy hot water and a plastic brush to clean the drain-lock of any built up of grim. If the drain-lock is to be removed for cleaning; wash it by hand at the nearest dump sink or run it through your dish machine. Before re-installing make certain all parts are in good conditions.
- Monitor that your Guardian Drain-Lock's are in place and secured/locked in place once a week to guarantee protection of your drain pipes.

